

# Sunflame<sup>®</sup>

Electric Kettle  
SF-188



## Sunflame<sup>®</sup>

Sunflame Enterprises Private Limited.  
58, Sector 27C, Mathura Road,  
Faridabad-121 003, Haryana, India

For complaint redressal you may either dial 1860 330 9999  
or e-mail us at [customercare@sunflame.com](mailto:customercare@sunflame.com) or  
write in at the above address.

[www.sunflame.com](http://www.sunflame.com)

## Instruction Manual

## INTRODUCTION

Dear Customer,

Congratulations!

You are now the proud owner of Sunflame Electric Kettle SF-188.

Please read this Instruction Manual carefully before using and keep it safely for future reference.

## IMPORTANT SAFEGUARDS

1. Read all instructions before using.
2. Before connecting the kettle to the power supply, check that the voltage indicated on the appliance (beneath the kettle or base) corresponds with the voltage in your home.
3. Do not let the cord hang over the edge of a table or counter or touch a hot surface.
4. Do not place on or near a hot gas, electric burner or heated oven.
5. Do not operate the appliance without water in it to avoid damaging the heating element.
6. Ensure that the kettle is used on a firm and flat surface, this will prevent the kettle from overturning and avoid damage or injury. Keep it out of reach of children.
7. To protect against fire, electric shock or personal injury, do not immerse cord, electric plug or kettle in water or other liquids.
8. While water is boiling, or just after the water has been boiled, avoid contact with steam from the spout.
9. Always take care to pour boiling water slowly and carefully without tipping the kettle too fast.
10. Be careful of refilling when the kettle is hot.


①

11. Persons with limited movement capacities, reduced sensory perception, insufficient mental capacity or those who are unaware of the proper handling, should not use this product. If they ever have to use the product, it should only be under the supervision of a responsible, aware person.
12. Children should be supervised to ensure that they do not play with the appliance.
13. Do not touch the hot surface. Always use the handle.
14. The kettle base cannot be used for other than intended use.
15. Always fill the kettle with water first, then set the appliance on to the power base, and finally plug the cord in to electric out let. To disconnect, remove the kettle body from the power base and then remove the plug from electric out let.
16. Extreme caution must be used when moving an appliance containing hot water.
17. The kettle is for household use only, do not use it outdoors.
18. The use of accessories, which are not recommended by the appliance manufacturer, may result in fire, electric shock or personal injury.
19. Unplug the kettle from the outlet when not in use and before cleaning. Allow the kettle to cool before putting on or taking off parts and before cleaning the appliance.
20. To disconnect, turn control to "off," then remove plug from the electric outlet.
21. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent in order to avoid a hazard.
22. Do not use the appliance for other than intended use.
23. The kettle can be only used with the base provided.
24. If the kettle is overfilled, boiling water may spill out.
25. Always ensure the lid is closed and do not open it while the water is boiling. Scalding may occur if the lid is opened during the brewing cycles.
26. This appliance is intended to be used for domestic purpose only.

②

## KNOW YOUR KETTLE

1. Body
2. Handle
3. ON/OFF switch
4. Spout
5. Lid lock
6. Power indicator
7. Power base unit



## TECHNICAL SPECIFICATIONS

<b>Model</b>	<b>Electric Kettle SF-188</b>
<b>Capacity</b>	<b>1.0 Ltr</b>
<b>Power</b>	<b>1350W</b>
<b>Voltage</b>	<b>220-240V AC</b>
<b>Frequency</b>	<b>50Hz</b>

③

## BEFORE FIRST USE

If you are using the kettle for the first time, it is recommended that you clean your kettle before use by boiling a full kettle of water (max limit) twice and then discarding the water.

## OPERATION

### TO FILL

Fill up to the maximum level as marked on the inside body of the kettle.

### DO NOT OVERFILL

As water may overflow upon boiling

### BOILING WATER

#### 1. Placing the kettle

Place the kettle with the spout facing away from you. Gently lift off the lid

#### 2. Filling the kettle.

Fill the kettle with clean water. The maximum amount of water to be used is indicated by the MAX FILL level.

#### 3. Closing the lid.

Position kettle with spout facing away from you. Close the lid.

#### 4. Placing kettle on power base

Place the kettle on the power base so that the element on the bottom of the kettle sits securely on the power base.

#### 5. Power "ON"

Press the power "ON" switch by gently pushing down until a "click" is heard. When the water has boiled, the kettle will automatically switch "OFF"

**NOTE:** The kettle can be switched off at any time before the water boils simply by lifting the kettle off the base.

#### 6. Pour and Serve.

Pour water out slowly and return kettle to base after pouring.

④

## CAUTION

1. Always disconnect from the main supply before emptying or cleaning the kettle and always switch off power point when not in use.
2. Never immerse kettle or power base in water or allow water to come into contact with the terminal pins.
3. Do not allow power cord to overhang from edge of a table or touch hot surfaces

## BOIL-DRY PROTECTION

Should you accidentally allow the kettle to operate without water, the boil-dry protection will automatically switch it off. If this happens, allow the kettle to cool before filling it with water and re-boiling.

## CLEANING AND MAINTENANCE

Always disconnect the appliance from the power outlet before cleaning. Never immerse the kettle or cord in water, or allow moisture to come in contact with these parts. Use soft damp cloth to wipe outer surface of kettle. Do not use any toxic detergent to clean your kettle.

## REMOVAL OF MINERAL DEPOSITS

Your kettle should be periodically descaled as the mineral deposits in tap water may form scale at the bottom of kettle interior. This will make the kettle less efficient. You can use the commercially available descaler and follow the instructions on the package of descaler. Alternatively, you may follow the below instructions to use white vinegar.

1. Fill the kettle with 1/3 cup of white vinegar, then add water till minimum level marking in the kettle. Leave the solution in the kettle overnight.
2. Discard the mixture in the kettle, then refill the kettle with clean water, reboil and then discard the water. Repeat several times until the odor of vinegar has been flushed away. Any stains remaining inside the spout can be removed by rubbing with a damp cloth.

## STORAGE

When not in use, the power cord may be wound around the cord storage under the bottom of kettle. Store the kettle in a cool and dry place.

## IMPORTANT NOTE

In view of continuous improvements, the design, specifications and features of the product are subject to change without prior notice.