



Sunflame Enterprises Private Limited
58, Sector 27C, Mathura Road,
Faridabad-121 003, Haryana, India

Incase of any suggestion / complaint, please
contact customer care at 1860 330 9999 or
e-mail at customer care@sunflame.com or
write in at the above address.

www.sunflame.com

Cover Back



Quartz Heater
SF-941



Read all instructions carefully before use

Cover Front


IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be observed, including the following:-

- Please read instructions carefully before using the appliance.
- This appliance is for household use only.
- Check that the mains voltage corresponds to that stated on the rating label of the appliance.
- Only responsible person should operate the appliance. Keep this appliance out of reach of children or incompetent persons.
- Make sure, not to place the power cord near sharp objects or hang over an edge of a table. Do not run/Place the cord of the heater under carpeting and do not cover the cord with loose rugs, runners or something similar. Arrange the cord away from walkways in order to avoid anyone tripping over it. Do not wind the power cord around the appliance and do not bend it.
- Please check the power cord for damages from time to time. Do not operate the heater with a damage cord or plug, or after the heater malfunctions, has been dropped, or damaged in any manner. Kindly take it to the nearest authorized service center for repair.
- Never use this appliance on or near hot surfaces.
- Avoid the use of an extension cord as it may overheat and cause a risk of fire.
- Before operating the appliance always make sure that it has been placed on a flat and stable surface.
- Never cover the appliance with a cloth or something similar when it is in use.
- The heater must not be placed near an electrical outlet while it is in operation. Make sure that the heater is never facing the power socket when it is in operation.
- Use the heater in a well-ventilated area. To prevent a possible fire, do not block the front portion, air intakes or exhaust openings of the heater in any manner. Do not use the heater on soft surface.
- Do not place this heater near flammable materials, surface or substances such as curtains; draperies etc, as there may be a risk of fire. Keep these flammable materials at least 2 meters away from all sides of the heater.

- Do not use the heater in any areas where petrol, paint or other flammable liquids are stored e.g. garages workshops etc. as the heater becomes hot while in operation and this can lead to a very dangerous situation.
- Never use this heater in immediate surroundings of a bath, shower or a swimming pool. Never place the heater at a place, when it may fall into a bathtub or other water/ liquid containers. This can be very dangerous.
- This heater is hot when in use. To avoid burns and personal injury, do not let bare skin touch hot surfaces.
- Always make sure that no other appliances are in use on the some electrical circuit/point as this product. This may cause an overload.
- Do not insert any foreign objects through the front grill/guard of the appliance as there is a danger of electric shock doing so and this will also damage the product.
- When the appliance is not in use always unplug the cord from the power supply.
Do not attempt to remove the plug from the wall socket with wet hands or by pulling the cord.
- Never use the appliance outdoors and always place it in a dry environment.
- Never immerse the appliance or its parts in water or any other liquids for cleaning purposes, as this will damage the product and create a risk of electric shock. Follow the instructions in section “Cleaning & Care” of this manual.
- Any repair required, should be undertaken by an authorized service center. Never try to repair the product yourself or by any unauthorized person.
- Never use this product for other than its intended use.
- Save these instructions for future reference.

PART IDENTIFICATION



1. Front Grill
2. Quartz Tubes
3. Control Switches
4. Smart Carry Handle
5. Tip-over Safety Switch
6. Power Indicator

TECHNICAL SPECIFICATION

Model	SF-941
Power Supply	230V 50 Hz, AC Single Phase
Wattage: 1st Switch (Left) 2nd Switch (Right)	400W 800W
Quartz Heating Tubes	2 Nos. (400W each)
Safety Device	Provided with a safety Tip Over Switch at the base which switches OFF the heater in case it tilts or falls.

HOW TO OPERATE AND MAINTAIN

ASSEMBLY

Take the heater out of its packing box carefully. Remove all the packaging and keep it out of reach of children. Keep the heater in upright position. Connect the power plug. Since the tube is made of Quartz, it needs 10-20 seconds to light up and heat.

PLACEMENT GUIDE FOR THE HEATER

While in operation, the heater should be placed in such a manner that its back is at least at a minimum distance of **1 Feet** from the wall and there should be a clear distance at the front.

OPERATING THE APPLIANCE FOR THE FIRST TIME

When the appliance is switched on for the first time, it may emit a slight smell. Please do not worry as the smell will disappear shortly. Please ensure sufficient ventilation during this time.

FUNCTION CONTROL

When Left switch is at ON position it will start operating bottom tube (400W) and when Right switch is at ON position it will result in the second tube to operate as well (800W)

CLEANING & CARE

1. Always make sure to disconnect the heater from the power supply and allow the heater to cool down completely, before you start cleaning the heater.
2. Never immerse the heater or its parts, power cord or plug in water to any other liquids for cleaning.
3. The main body of the heater may be wiped clean with a slightly damp, lint free cloth and then with a soft dry cloth.
4. Do not use any cleaning chemical such as detergents and abrasives, as this will damage the product beyond repair.
5. When not in use, always store the heater in a clean and dry place.
6. In case of any malfunction, do not try to repair the product yourself or by any unauthorized person, as this may result in a fire hazard or electric shock. Always contact the nearest authorized service center.

FEATURES AND SAFETY DEVICES

TIP-OVER SAFETY FEATURE

This heater comes with a tip-over safety feature. If the heater is tilted or tips over while in operation, it switches off immediately for safety. In this case, kindly unplug the appliance from the power outlet, place the heater correctly on a stable and flat surface and then switch it on again.

OTHER SAFETY FEATURES

- The Heater is provide with 2 Heating options which enables you to use the the Heater in different climatic conditions economically.
- The Heater is provided with “UNIQUE SAFETY DEVICE “which switches OFF the heater if it tilts of falls. This safety device is provided at the base of the heater.
- This Heater saves energy as it consumes very less electricity (400/800W), thereby saving in electricity bills.
- The Heater has powder coated body which provides excellent corrosion resistance and it leads to much longer life in respect of both looks and strength.

NOTE

In view of continuous improvement, the design and specifications of the product are subject to change without prior notice.